


THE
RABBIT
COMPANY™

OVERVIEW


All products by **The Rabbit Company**[™] are made from soft, smooth, body safe materials.

Our easy to use interface allows users to easily find the right stimulation and intensity. Get ready for sensual satisfaction that can not be matched and will have you craving for more.




The Couples Rabbit™

THE COUPLES RABBIT



WIRELESS REMOTE CONTROL




GETTING STARTED

1. Before first use, charge your rabbit for approximately 2 hours. The USB charging cable can be plugged into any USB port or USB/AC power adapter (not included).

- Flashing Light = Charging
- Solid Light = Fully Charged
- Rapid Flashing Light = Low battery, charge is needed

2. Wash your rabbit with soap and water, or toy cleaner suitable for use with silicone items.




Please ensure the rabbit icon faces the ears of the rabbit during charging.





FAQs can be found at
www.TheRabbitCompany.com


Email us at
customer care@TheRabbitCompany.com
for any unanswered questions

3. Lubricate your rabbit (if needed) with a water based, silicone compatible lubricant.

4. Turn ON your rabbit by pressing  quickly. The light will flash, indicating the power is on and in standby mode.



Push  again on your rabbit to use the manual mode, or push  on the remote to pair the remote & rabbit.

Once in use, the light will change from flashing to solid.






5. To change the vibration pattern via manual control, press the .


6. To change the vibration intensity via the remote control press and release **+** (Increase Intensity) and **-** (Decrease Intensity).








MANUAL CONTROL



1. To turn the item ON quickly press  on your rabbit. The  will flash to indicate the power is on. Push  again to change the vibration pattern. There are a total of 6 modes using the manual control.


2. To power OFF your rabbit press  and hold for 2 seconds. LED will turn off to indicate the power is OFF.





REMOTE CONTROL

1. First turn your rabbit on in standby mode by quickly pressing  on your rabbit.
2. While the light is flashing, press  to power on your remote and to pair the remote & rabbit.
3. Once the item is paired the light on the rabbit () will become **solid** and you can control your rabbit by remote.
4. Press and release  on the remote to increase vibration intensity.
5. Press and release  on the remote to decrease vibration intensity.





6. To change the vibration pattern, press and release  on the remote.

7. Holding  for 3 seconds will pause vibration. Quickly pressing  resumes vibration.

8. To turn the item ON/OFF press and release  on the remote.

9. To completely turn off your rabbit, press and hold  on your rabbit.




CHARGING

- Attach the USB charging plug to the designated magnetic charging area on the top of the rabbit. Please ensure the rabbit icon faces the ears of The Couples Rabbit during charging.

- Flashing light indicates item is charging

- Solid light indicates item is fully charged

- The Couples Rabbit requires approximately **2** hours for full charge



Flashing light = Charging




Solid light = Fully Charged



CHANGING YOUR REMOTE CONTROL BATTERY

- Slide open the remote control battery compartment as shown.
- Button cell CR 2032 has been preinstalled into the remote control.
- Remove the paper slip inside the battery compartment to activate the power in the remote control.
- Suggested to remove the battery from the remote control for extended storage. Store the remote control and the battery separately.



TRAVEL LOCK



The Rabbit Company™ items include a travel lock for safe and convenient travel.


For the remote:

Simultaneously press and hold the + and – buttons for 3 seconds. Flashing light will indicate the item is locked.

To unlock simply press and hold + and – again for 3 seconds. Flashing light will indicate lock is disabled.

For the rabbit:

Hold  for 5 seconds, flashing light will indicate the item is locked. For unlocking, hold  again for 5 seconds, flashing light will indicate the item is unlocked.



VIBRATING MODES

Internal / External Stimulator

1. Constant



2. Wave



3. Pulse



4. Ascend



5. Oscillate




6. Random



HARE CARE™

Cleaning, Storage & Safety

1. Always clean your rabbit thoroughly before and after each use.
2. We recommend using a premium water-based lubricant when needed. Silicone-based lubricants are not recommended and can cause damage to the product. Never use hand cream, or massage oils as lubricants for your intimate areas.
3. To properly clean your rabbit, use a suitable silicone-compatible toy cleanser. If this is not available, wash the silicone area of your rabbit with luke-warm water and an antibacterial soap. Rinse clean and pat dry using




a lint-free cloth or towel. Do not use cleaners containing alcohol, petrol or acetone.

4. Avoid leaving your rabbit in direct sunlight and never expose it to extreme heat.

5. Our products are designed to be splash-proof. Never immerse your rabbit in water.

If your rabbit appears to function abnormally, turn OFF and consult our customer care section on **TheRabbitCompany.com** where you will find help tips. Should you require further assistance please contact:
customercare@TheRabbitCompany.com



SPECIFICATIONS

Materials	Body Safe Abs / Silicone
Size	32 x 85 x 58 mm
Weight	64 g
Battery	150 mAh
Charging	2 hours
Use Time	1 hour
Max Noise Level	< 68 dB
Interface	Single Button Manual Control 5 Button Remote Control
Modes	11 modes

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):



RoHS



The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.

Complete user instructions in additional languages can be found at:

www.TheRabbitCompany.com

FAQs can be found at
www.TheRabbitCompany.com

Email us at
customercare@TheRabbitCompany.com
for any unanswered questions

Sold as a novelty only. Made and packed in China. All rights reserved. The shape and appearance of the products in this guide are a trademark and trade dress of B.C.B.V.I © 2018

Visit www.trcpatents.com for more info.

IMPORTANT SAFETY INFORMATION

- Do not expose the Couples Rabbit to fire or water.
- Do not attempt to disassemble the the Couples Rabbit t yourself. Please contact after-sales service if there is an issue.
- The battery used in the Couples Rabbit is a non-chargeable battery. Do not try to charge it.
- The Couples Rabbit contains small parts such as battery, battery cover. The small parts are not toys, do not allow children to play with them to prevent the risk of suffocation.
- Risk of safety issue if the battery is replaced by an incorrect type.
- Dispose of used batteries according to instructions.
- Do not ingest battery. Chemical Burn Hazard.
- The Couples Rabbit contains a coin/button battery. If the CR2032 cell is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children.
- If the battery compartment does not close securely, stop using the product and keep it away from children.
- Replacement of a battery with an incorrect type that can defeat a safeguard.
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Designed and Developed by
The Rabbit Company™

Made in China
© The Rabbit Company™

TheRabbitCompany.com

v2.0